



| | | | | | | | | | | | | | | | | | | | |
|---|---------|---------|---------|---------|---------|---------|---------|---------|---------|---------|---------|---------|---------|---------|---------|---------|---------|---------|---------|
| HARNESS N° | 5657513 | 5657582 | 5657523 | 5657533 | 5657534 | 5657535 | 5657536 | 5357537 | 5657540 | 5657541 | 5657581 | 5657553 | 5657551 | 5657554 | 5657560 | 5657579 | 5657565 | 5657569 | 5657572 |
| Plug to supply | 23B | 23B | 35A | 35A | 35A | 35A | | 35B | 23B | 23B | 23B | | 23B | 2 | 23B | 35B | 35B | | 23 B |
| Electrical connexion | | | | | | | | | | | | 6² | | | | | | 6² | |
| Module to spray | | | X | X | X | X | | | | | | X | 5657528 | | 5657528 | | | X | 5657528 |
| Module to hydraulic | X | | | | | | | X | X | | | | | | | X | X | X | |
| Ergo handle | | | | | | | X | | | | | | | | | | | | |
| AVENTA control box | | | | | | | X | | | | | X | | | | | | X | |
| Extension cable of loom electrical of box AVENTA supply | | | | | | | | | | | | | | | | | | | |
| VOLUTIS control box | | | | | | | | | | | | | | | | | | | |
| AUTONET | | | | | | | | | | | | | | | | | | | |
| Solenoid valves to spray | | | 7SV | 4SV | | | | | | 1SV | 1SV | | 4SV | | 2SV | | | | |
| Solenoid valves of return | | | X | X | X | X | | | | | | | | | | | | | |
| Pneumatic valves of return | | | | | 4SV | 7SV | | | | | | | | | | | | | |
| Flowmeter to spray | | | | | | | | | | | | | | X | | | | | |
| Flowmeter to filling | | | | | | | | | | | | | | | | | | | |
| Filling valve | | | | | | | | | | | | | | | | | | | |
| Motor-driven valve | | | | | | | | | | | | | | X | | | | | |
| Buzzer to boom | | | | | | | | X | | | | | | | | X | X | | |
| Main tank full level buzzer alarm | | | | | | | | | | | | | | | | | | | |
| Main tank full level sensor | | | | | | | | | | | | | | | | | | | |
| Rinse tank low level sensor | | | | | | | | | | | | | | | | | | | |
| Speed pickup | | | | | | | | | | | | | | X | | | | | |
| Extension cable speed pickup LASER 1800 | | | | | | | | | | | | | | | | | | | |
| Hydrauma + hydraulic central | 2SV | 6SV | | | | | | 9SV | 6SV | 6SV | | | | | | 9SV | 9SV | | |
| Hydraulic control selector | | | | | | | | 2SV | | | | | | | | 2SV | 2SV | | |
| Latch boom (hydraul.) | | 2SV | | | | | | | 2SV | 2SV | | | | | | | | | |
| Latch boom (contact.) | | X | | | | | | X | | | | | | | | X | | | |
| 3/4 folding boom | | 2SV | | | | | | | 2SV | 2SV | | | | | | | | | |
| GV boom | 2SV | 2SV | | | | | | | 2SV | 2SV | | | | | | | | | |
| U/F arm of boom (hydraul.) | | | | | | | | 2SV | | | | | | | | 2SV | 2SV | | |
| U/F arm of boom (contact.) | | | | | | | | | | | | | | | | X | X | | |
| U/F boom fore-arm | | | | | | | | 2SV | | | | | | | | 2SV | 2SV | | |
| Up/down boom lift | | | | | | | | 1SV | | | | | | | | 1SV | 1SV | | |
| Tilt correction of boom (hydraul.) | | | | | | | | 2SV | | | | | | | | 2SV | 2SV | | |
| Tilt correction of boom (contact.) | | | | | | | | | | | | | | | | | X | | |
| Right latch | | | | | | | | | | | X | | | | | | | | |
| Left latch | | | | | | | | | | | | | | | | X | | | |
| Plug 2 | | | X | X | X | X | | | | | | | | | | | X | | |
| Plug 3 | | | | | | | | | | | | | | | | | | | X |



FOOT-NOTE: To check the marking of the electrical harness on the apparatus



Tecnoma 
technologies

VOLUTIS

VOLUNTIS

AUTONET

AUTONET

AUTONET

FOOT-NOTE: To check the marking of the electrical harness on the apparatus